

## Water Levels

### “UM” MODEL

Water consumption chart in gallons (liters).

Water Level inches (cm)	Volume Gallons (Liters)
0	0.01 (.2)
1 (2.5)	2.0 (7.6)
2 (5.1)	3.9 (14.9)
3 (7.6)	5.9 (22.3)
4 (10.2)	7.8 (29.6)
5 (12.7)	9.8 (36.9)
6 (15.2)	11.7 (44.3)
7 (17.8)	13.6 (51.6)
8 (20.3)	15.6 (58.9)
9 (22.9)	17.5 (66.2)
10 (25.4)	19.4 (73.5)
11 (27.9)	21.4 (80.9)
12 (30.5)	23.3 (88.2)

Allowance is made for filling the drain line up to the wash compartment (0 inches). Water consumption figures are based on an empty washer (no load).

To allow for saturation of dry load:

Add 0.25 gallons/pound (2.09 liters/kilogram) to appropriate figure from above.